



D65 MKI SX HYDRAULIC MAIN PUMP

BMS-3222337038 NOW IN STOCK \$4,000.00



**Pump 1 – SX Hydraulic
Main Pump**

Suits Epiroc D65 Mk1

Contact us now:
info@breakoutmechanical.au





UNDERCARRIAGE COMPONENTS

BMS-3222349206 - Track Frame – RH

BMS-3222349205 - Track Frame – LH

BMS-3222338731 - Idler Group

BMS-3222346751 – Final Drive Unit incl Motor

BMS-3222329874SX - Final Drive Unit incl Motor (SX)

BMS-3222359522SX - Final Drive w/o Motor

BMS-3222346860SX - Final Drive Motor (A6VE55)

BMS-FD-MG-PLG-K - Magnetic Final Drive Plug

BMS-3222338743 - Tramming Motor Cover – RH

BMS-3222338743 - Tramming Motor Cover – LH

BMS-3222343601 - Track Group

BMS-3222349002 - Track Roller

BMS-3222338730 - Carrier Roller

BMS-3222338732 – Sprocket

BMS-3222340046 - Pivot Shaft Bush

BOOM SYSTEM

BMS-3222319996SX - SX Boom Attachment

BMS-3222319996 - Boom Attachment



BOOM SYSTEM

BMS-0500450088 - Plain Bearing

BMS-0500450106 - Plain Bearing

BMS-3222320700SX - SX Boom

BMS-3222320700 – Boom

BMS-3222331597 - SX Boom Head Complete (Knuckle)

BMS-3222331597 - Boom Head Complete

BMS-3215824600 – Bushing

BMS-0500450017 - Plain Bearing Busing

BMS-3222304202 – Shaft

BMS-3222310227 – Shaft

BMS-3222310225 – Shaft

BMS-3222323241 – Shaft

BMS-3222325111 - Expander Pin (includes end caps & hex screw)

BMS-3222339651 - Hex Screw (for BMS-3222325111 Exp Shaft)

BMS-3222310226 – Shaft

BMS-3222310223 – Shaft

BMS-3222305657 - Expander Shaft

BMS-3222036016 - Bearing Ring

BMS-3222308395 - Shaft Compl. BMS-3222316176 - Expanding Shaft
(includes end caps & hex screw)



BOOM SYSTEM

BMS-0047111100 - Hex Screw (for BMS-3222316176 Exp Shaft)

BMS-0500450133 - Plain Bearing

BMS-3222321013SX - SX T45 Feed Holder

BMS-3222321013 - Feed Holder

BMS-3222349977 - Boom Lift Cylinder

BMS-0335110410 – Circlip

BMS-0324155163 - Back-Up Ring

BMS-3125512800 - Lock Plate

BMS-3128307488 - Sliding Piece

BMS-3128061900 – Key

BMS-3128078439 - Holder LH

BMS-3128078438 - Holder RH

BMS-3222316289 – Cover

BMS-3222327363 – Holder

BMS-3222327365 – Holder

BMS-3222315815/BMS-3222364377 - Hydraulic Cylinder

BMS-3222349974/BMS-3222370032 - Hydraulic Cylinder

BMS-3222349974SX/BMS-3222370032SX - Hydraulic Cylinder

BMS-3222330061/BMS-3222370036 - Boom Swing Cylinder



BOOM SYSTEM

BMS-3222330061SX/BMS-3222370036SX - Boom Swing Cylinder

BMS-3222312071/BMS-3222370029 - Hydraulic Cylinder

BMS-3222327951 – Washer

BMS-3222312947SX/3222370057SX - Hydraulic Cylinder (swing)

BMS-3222328806SX/3222372127SX - Hydraulic Cylinder (feed swing)

BMS-3222349977SX - Boom Lift Cylinder

BMS-0500450129 - Plain Bearing

BMS-3222310222 – Shaft

EXHAUST SYSTEM

BMS-3222339572 – Muffler

BMS-3222348710 - Muffler Clamps

DRILL CARRIAGE

BMS-3128306163 - Slide Holder

BMS-3218306164 - Slide Holder

BMS-8232300086/3222370022 - Hydraulic Cylinder (Osc)

BMS-8232300086SX/3222370022SX - Hydraulic Cylinder (Osc)



DRILL CARRIAGE

BMS-3222334402 – Shaft

BMS-3222310230 – Shaft

BMS-3222326972 – Plate

BMS-3222334204– Shaft

BMS-3222330180 - LH Wide Body Console

BMS-3222330183 - RH Wide Body Console

BMS-3222330180SX - LH Wide Body Console

BMS-3222330183SX - RH Wide Body Console

BMS-3222333127 - Eccentric Shaft

BMS-3222330758 – Spacer

BMS-3222331589- Door Right Hand

BMS-3222331592 - Door Right

BMS-3222317500 - Door Complete

BMS-3222331605 – Door

BMS-3222338737 – Cover

BMS-3222338743 – Cover

BMS-2657552754 - Ring Seal

BMS-3222339007 – Pin

BMS-0101195161 - Parallel Pin



DRILL CARRIAGE

BMS-3128253836 - Lubricating Grease Pump

BMS-3222355961 - Holder Set

BMS-3222342999 - Water Filter

BMS-5730009853 – Bolt

ELECTRICAL

BMS-3222337692 - Cable

BMS-3222367309 – Cable

BMS-3222354160 – Cable

BMS-3176001739 - Can Open Cable

BMS-3176001114 - Signal Cable

BMS-3176001124 - Signal Cable

BMS-3222315892 – Splitter

BMS-3222322591 - Signal Cable

BMS-3222361916 – Cable

BMS-9772026027 - Gate Switch

BMS-9106132490 - Address Plug

BMS-9106220702 - Address Plug

BMS-3222342150 - Induction Sensor



ELECTRICAL

BMS-3222343371 - Level Sensor

BMS-9106971739 – Cable

BMS-3176001190 - Signal Cable

BMS-3222323717 - Signal Cable

BMS-3222321305 - Cable Complete

FEED

BMS-3222347002 – FEED BEAM D65 MKII

BMS-3222347001 - T45 FEED BEAM D65 MK1/T45

BMS-3222342456 - Splined Shaft

BMS-3222343113 - Bearing Unit

BMS-3222319985 – Shaft

BMS-0108137000 - Spring Pin

BMS-0500450016 - Flange Bearing

BMS-0108136600 - Spring Pin

BMS-3222349783 – Arm

BMS-3222312503 – Shaft

BMS-3222349784 - Guide Plate



FEED

BMS-0500450024 - Flange Bushing

BMS-3222326110 – Holder

BMS-3222338361 - Hydraulic Cylinder (Gripper Jaw)

BMS-3222325055 - Bushing Half (T51)

BMS-3222336148 / 3222351457 - Hydraulic Cylinder

BMS-0501000028 – Bearing

BMS-0501000010 – Bearing

BMS-3222340004 – Spacer

BMS-3222338525 - Hose Drum

BMS-0500453620/0500450122 – Bearing

BMS-3222341097 - Hose Drum

BMS-3222338380 – Pipe

BMS-3222341697 – Pipe

BMS-3128078430 - Pulley Wheel

BMS-0666800704 - Axial Seal

BMS-0666671800 - Radial Lip Seal

BMS-3128048500 – Plate

BMS-3128078549 - Holder (left)

BMS-3222338956 - Sprocket Wheel



FEED

BMS-3128240703 - Bushing Halves (F9)

BMS-3222063700 - Jaw (gripper arm)

BMS-3222343508 - Expanding Shaft

BMS-3222310385 – Shaft

BMS-0501001300 – Bearing

BMS-0335214100 – Circlip

BMS-3222064100 – Shaft

BMS-3222311719 – Shaft

BMS-0335214300 – Circlip

BMS-0666800027 - Seal Axial

BMS-3222319777 - Carrier Unit

BMS-0333611200 – Washer

BMS-0295311200 - Lock Nut

BMS-0500450094 - Flange Bearing

BMS-3222327513 – Carrier

BMS-3222323847SX - Feed Dump Cylinder

BMS-3222333512/3222351455 - Gripper Cylinder

BMS-3222310744 - Arm Cylinder RHS

BMS-3222351454 - Centraliser Cylinder



FEED

BMS-3222317029 - Hydraulic Cylinder

BMS-3128000451 - Hydraulic Cylinder

BMS-0666810017 - Axial Seal

BMS-3222328551 - Check (jaws)

BMS-3222342902 - Drill Steel Support Half (T51)

BMS-3222333518 - Hydraulic Cylinder (rod gripper)

BMS-3222338813 - Feed Motor

BMS-3222148906 - Check Jaw

BMS-3222175605 - Check Jaw

BMS-3128240702 - Bushing Half

BMS-322219987SX – Attachment

BMS-3222314269 - Shaft (plate)

BMS-3222312501 – Shaft

BMS-3222351085 - Hose Drum

BMS-3222325104 - Bottom Plate

BMS-3222322162 – Damper

BMS-3222325103 - Gable Plate

BMS-3217112900 - Lock Plate

BMS-3222312499 – Cover



FEED

BMS-3214253600 – Sprocket

BMS-0502122900 - Ball Bearing

BMS-3215921400 - Spacer Ring

BMS-3222312500 – Shaft

BMS-3128240500 – Shaft

BMS-3222341161 - Hydraulic Cylinder

BMS-3222340786 – Arm

BMS-3222312453 – Attachment

BMS-3222301840 – Arm

BMS-3128240300 – Jaw

BMS-0500450061 – Bushing

BMS-3222312502 – Arm

BMS-3222312940 – Attachment

BMS-3222332624 – Jaw

BMS-3128306180 - Slide Holder

BMS-3128306181 - Slide Holder

BMS-3222319533 – Plate

BMS-3222320895 - Centraliser Jaw Half

BMS-3222313347 – Screw



FEED

BMS-3222333510/BMS-3222321529 - Breakout Cylinder

BMS-3222343058 - Slide Bar 3.125m

BMS-3222319768SX - Turning Cylinder

BMS-0500450033 - Flange Bearing

BMS-3222312503 – Shaft

BMS-3222342457 - Sprocket Wheel

BMS-3222340374 – Guide

BMS- 3222338961 - Shaft Assembly

BMS-3222323245 - Roller Bearing

BMS-0335117300 – Circlip

BMS-3222319922 - Hydraulic Cylinder

BMS-3128305639 – Shaft

BMS-3222355348 - Drill steel support half

BMS-3222361422 – Spacer

BMS-0500451050 - Slide Washer

BMS-0504020037 - Ball Bearing

BMS-0666458900 - Seal Ring

BMS-3222315328 – Spacer

BMS-3222325967 – Spacer



FEED

BMS-0500450065 - Flange Bearing

BMS-0666200034 - Radial Lip Seal

BMS-0509011500 - Roller Bearing

BMS-0333611500 - Lock Washer

BMS-0295311500 - Lock Nut

BMS-3222318003 - Set Screw

BMS-3222320740 – Shim

BMS-3222323974 – Shaft

BMS-0663616700 - O-Ring

BMS-0663617100 - O-Ring

BMS-3128302018 – Shim

BMS-3222323973 – Washer

BMS-3128300268 - Piston Rod End

BMS-3222338363 - Hydraulic Cylinder

BMS-3222311362 – Spacer

BMS-3222357707 – Plate

BMS-3222353134 – Fundament

BMS-3222323706 – Fundament

BMS-3222145900 - Rubber Buffer



FEED

BMS-3222357706 – Hook

BMS-3222315329 – Pivot

BMS-0335112200 – Circlip

BMS-3222319752 – Shaft

BMS-3222319753 – Cover

BMS-3222339625 – Shaft

BMS-3222339624 - Chain Bracket

BMS-3222338892 - Chain Bracket

BMS-3222358797 - Tension Screw

BMS-3222358839 - Chain Tensioner

BMS-3222339618 - Cradle Plate

BMS-3222322077 – Gasket

BMS-3222310366 - Star Wheel

BMS-3222347092 - Vibr Damper

BMS-3222347091 - Vibr Damper

BMS-3222347124 – Plate

BMS-3222347372 – Spacer

BMS-3222339613 – Pipe

BMS-3222340277 – Guide



FEED

BMS-3222339615 – Protection

BMS-3222338958 – Shaft

BMS-3222339584 – Bearing

BMS-0335215200 – Circlip

BMS-0335114000 – Circlip

BMS-3222339238 – Plate

BMS-3222339239 – Plate

BMS-3222326112 – Attachment

BMS-3222193800 - Feed Motor Sprocket

BMS-3222320910 – Shaft

BMS-3222320918 – Shaft

BMS-3125021300 – Bushing

BMS-3222331366 – Bushing

BMS-3222327121SX/3222364373SX - Feed Swing

BMS-3128302018 – Shim

BMS-0335217100 – Circlip

BMS-3222340256 - Seal Kit

BMS-8232300137 - Hydraulic Cylinder

BMS-3222310708 - Sprocket (F9)



FEED

BMS-3216538200 - Sheave Bearing

BMS-0335116000 – Circlip

BMS-3222321479/3222321480 - Slide Bar - 6.818M

BMS-3222353105/3222353104 - Slide Bar – 3.125M

BMS-3222326589 - Slide Bar – 1.595M

BMS-0335213200 – Circlip

BMS-0500450129 - Plain Bearing

BMS-3222326144 - Pinch Bar Housing (upper)

BMS-3222306188 – Arm

BMS-3216934742 – Shaft

BMS-0516413901 - Inner Ring

BMS-3222311333 - Foot Beam

BMS-8232300135 - Hydraulic Cylinder

BMS-3222099401 – Shaft

BMS-3222099400 – Shaft

BMS-3222326122 - Support Housing (lower front)

BMS-3222342446 - Chain Tensioner

BMS-3222326058 - Lamp Attachment

BMS-3222311363 - Piston Rod End



FEED

BMS-3222345362 - Bulkhead Connection

BMS-3222343524 - Valve Attachment

BMS-3222343528 - Attachment Complete

BMS-3222343535 – Cover

BMS-033521800 – Circlip

BMS-0335216500 – Circlip

BMS-0501001900 – Bearing

BMS-0501002000 – Bearing

BMS-0501001800 – Bearing

BMS-3222341662 - Turning Cylinder

BMS-3222331060 – Check

BMS-3222325056 - Bushing Half

BMS-3128301389 - Piston Rod End

BMS-3222325222 – Hub

BMS-3315019510 - Lock Washer

BMS-3222310362 - Star Wheel

BMS-3222330810 – Shim

BMS-3222323265 – Shim

BMS-6060003430 – Valve



FEED

BMS-3222370108 - Feed Cylinder (T40)

BMS-3222330090 - DR.ST.Supp.Half

BMS-3222316982 - Rubber Disc

BMS-3222335387 – Spacer

BMS-3222063710 – Jaw (gripper arm)

ENGINE

BMS-CAT C15 – Poly Vee

BMS-3222308136 – Washer

BMS-3222330284 - Rubber Damper

BMS-0653122700 - Flat Gasket

BMS-3222342419 – Valve

BMS-3222311570 – Gasket

BMS-3222331347 – Seal

BMS-6060001155 - Rubber Moulding

BMS-3222331329 - Rubber Moulding

BMS-3222333482 - Seal Kit

BMS-3222324301 - Rubber Socket

BMS-0337530500 – Key



COMPRESSOR

BMS-2642441287 - BMS-2658356577 - Air Compressor

BMS-2642441287SX - BMS-2658356577SX - Air Compressor SX

BMS-3222332270 - SI - Silicon Element

BMS-M07 1.57 Air End SX

BMS-2653307054 - Rubber Element

BMS-2653261327 - Flange Drive

BMS-3115164801 – Coil

BMS-3222290119 - Radiator Cap

BMS-1615639900 – Flange

BMS-1616510800 - Level Gauge

BMS-3222336731 – Element

BMS-1604133001 – Retainer

BMS-0663313400 - O'Ring

DRIFTER

BMS-COP3060 (second hand)

BMS-3115192602 – Diaphragm

BMS-3115219681 - Test Valve



COOLER

BMS-3222349762SX – Cooler Assy

BMS-3222340520 – Engine Radiator

BMS-3222340520SX – Engine Radiator

BMS-3222340521 - Charge Air Cooler

BMS-6060001276 – Charge Air Cooler

BMS-6060003179 – Compressor Oil Cooler - Lower

BMS-3222330285 - Wing

BMS-3222330289 - Vibration Damper

HOLE NAVIGATION SYSTEM (HNS)

BMS-3222322137 - HNS AN1 Feed Cable

BMS-3222342741 - HNS AN2 Wagon Frame Cable

BMS-3222342738 - AN3 Cabin Roof Cable

BMS-3222333728 - Adapter Cable

BMS-3222338911 - Trimble RS232 Cable

BMS-3222358705 - Cable Complete

BMS- 3222340418 - Holder (AN1 Feed ANT Bracket)

BMS-3222332520 - Holder (AN1 Antenna Mount)

BMS-3222323420 - Holder (AN2 Rig Antenna Mount)



HOLE NAVIGATION SYSTEM (HNS)

BMS-3222334447 - Holder (AN2 Pole Mount)

BMS-3222343138 - Holder Set (AN3 Roof Mount)

BMS-3222339470 - AN3 Antenna

BMS-3222342740 - HNS Wagon Frame Cable

BMS-5112209300 – Peg

HYDRAULIC SYSTEM

BMS-3222323210 - Gear Pump

BMS-3222332210SX - SX T45 Jack Leg

BMS-3222275610SX - D65 Jack Leg Cylinder

BMS-3222331858 – Sensor

BMS-3222334721 - Seal Kit

BMS-3128253801 - Pump Element

BMS-3222322246 - Relief Valve

BMS-3222340192 – Valve

BMS-3222340535 – Valve

BMS-3222337152 - Temp Sensor

BMS-1604707600 – Membrane

BMS-0666800017 – Vring



HYDRAULIC SYSTEM

BMS-6060000228 - Safety Valve

BMS-3222371224 - Valve Reducing Pressure

BMS-3222368787 - Temp Sensor

BMS-3222373452 - Pressure Sensor

BMS-3222366988 - Pressure Relief Valve

CABIN

BMS-5541902100 – Fan

BMS-3222989648 – Chair

BMS-3222989426 - Weather Strip

BMS-3222986152 - Air Nozzle

BMS-3222989259 – Wire

BMS-3222989270 - Cab Handle

BMS-3222990122 – Knob

BMS-3222986201 - Wiper Blade

BMS-3222986131 - Flush Water Tank (inc 3 motors)

BMS-3222328907 - Air Nozzle

BMS-3222324901 - Valve TX Block

BMS-3222989245 – Shelf



CABIN

BMS-3222989515/0333314200 - Lock Washer

BMS-3222986235 - Gas Spring

BMS-3222361764 - Gas Spring

BMS-3222986153 - Glare Shield

BMS-3222989210 – Plug

BMS-3222986234 - Sealing List

BMS-3222986250 - Air Channel (with nozzles)

BMS-0217110022 - Sock Screw

BMS-3222341793 – Cover

BMS-3222989280 – Washer

BMS-3222349181 - Spray Nozzle

BMS-3222989376 - Sun Curtain

BMS-3222989375 - Glare Shield

BMS-3222989378 - Glare Shield

AIR CONDITIONING

3222324896 - Fan (Double Evap)

BMS-3222324914 – Reservoir

BMS-3222325995 - Pressure Switch



CONTACT FOR LATEST PRICING

info@breakoutmechanical.au

sam@breakoutmechanical.au

scottj@breakoutmechanical.au

1300 193 411